

Miscellaneous

		44
		61
DOORS OPEN	DOORS CLOSE	90
CYCLE START	CYCLE STOP	91
SEMI AUTO	AUTO	92
		131
		132
		133
		149
		150
		159
HAND	AUTO	166
DOG HOUSE UP	DOG HOUSE DOWN	174
SUB DS UP	SUB DS DOWN	204
SUB ODS UP	SUB ODS DOWN	205
SUB CYL DS	SUB CYL ODS	209
SUB CYL BOTH		210
SUB CYL UP	SUB CYL DOWN	211

SUB CYL DS	SUB CYL ODS	209
SUB CYL BOTH		210
SUB CYL UP	SUB CYL DOWN	211
JACK ODS1 UP	JACK ODS1 DOWN	212
JACK ODS2 UP	JACK ODS2 DOWN	213
JACK ODS3 UP	JACK ODS3 DOWN	214
JACK DS1 UP	JACK DS1 DOWN	215
JACK DS2 UP	JACK DS2 DOWN	216
JACK DS3 UP	JACK DS3 DOWN	217
		221
SUB CYL CENTER	SUB CYL ALL	227
		234
ARTICULATE A EXTEND	ARTICULATE A RETRACT	261
ARTICULATE B EXTEND	ARTICULATE B RETRACT	262
SUB RAISE	SUB LOWER	263
ARTICULATE EXTEND	ARTICULATE RETRACT	264
BRACE EXTEND	BRACE RETRACT	265
PIN EXTEND	PIN RETRACT	266

		280
GUARD OPEN	GUARD CLOSED	298
DOORS 		299
DOG HOUSE RAISE	DOG HOUSE LOWER	301
ARTICULATE 1 EXTEND	ARTICULATE 1 RETRACT	305
ARTICULATE 2 EXTEND	ARTICULATE 2 RETRACT	306
AUTO STOP	BOTH	307
KICKER CYL EXTEND		310
FOG	JET	311
MON		312
YOKE CLOSE	YOKE OPEN	316
BACK BAR DOWN	BACK BAR UP	317
KICK DOORS CLOSE	KICK DOORS OPEN	318
BELLY BAND UP	BELLY BAND DOWN	319
BACK LEG UP	BACK LEG DOWN	320
TAKE CONTROL		351
GATE 1	GATE 2	352
GATE 3	GATE 4	353

Miscellaneous

GATE 5		GATE 6	354
GATE 7		GATE 8	355
GATE 9		GATE 10	356
GATE 11			357
			386
RDTL MAINTENANCE		RDTL TRANSPORT	396
PTO		AIR FREE SPOOL	407
CONVEYER OFF/ON			411
CONVEYER SWING LEFT		CONVEYER SWING RIGHT	412
CONVEYER EXTEND		CONVEYER RETRACT	413
POD LIFT		POD LOWER	414
U		L	415
DIVERTER			420
TOP 1 OPEN		TOP 1 CLOSE	451
TOP 2 OPEN		TOP 2 CLOSE	452
TORQUE		DE TORQUE	456
			460
ZERO 		AUTO 	461

REAR G/N HATBOX DOWN		REAR G/N HATBOX UP	462
JEEP LEVEL LEFT		JEEP LEVEL RIGHT	463
JEEP AXLES RETRACT		JEEP AXLES EXPAND	464
JEEP AXLES LEFT		JEEP AXLES RIGHT	465
LOAD		UNLOAD	474
SQUEEZE		RELEASE	475
SCREEN VERTICAL		SCREEN RADIAL	495
CLEAR FUNCTION		LMD1	497
CLEAR FUNCTION		LMD2	498
BASE STONE UP		BASE STONE DOWN	499
BASE STONE LEFT		BASE STONE RIGHT	500
RIP RAP UP		RIP RAP DOWN	501
RIP RAP LEFT		RIP RAP RIGHT	502
1/4" MINUS UP		1/4" MINUS DOWN	503
1/4" MINUS UP		1/4" MINUS DOWN	504
1/2" UP		1/2" DOWN	505
1/2" LEFT		1/2" RIGHT	506
3/4" UP		3/4" DOWN	507

3/4" LEFT		3/4" RIGHT	508
HAT BOX DOWN		HAT BOX UP	531
			534
			541
			542
		AUTO 	543
RADIAL CW		RADIAL CCW	548
LEFT FD EXTEND		LEFT FD RETRACT	549
RIGHT FD EXTEND		RIGHT FD RETRACT	550
AIR IN		AIR DUMP	568
BIN #1		BIN #2	575
BIN #3		BIN #4	576
BELT START		VIBRATOR START	578
BELT STOP		VIBRATOR STOP	579
TOP CLAMP		TOP RELEASE	588
CENTRE CLAMP		CENTRE RELEASE	589
LOWER CLAMP		LOWER RELEASE	590
OPEN 		CLOSE 	591

Miscellaneous

		592
		595
		596
		597
		598
		599
RELEASE	SQUEEZE	600
		611
FD UP	FD DOWN	612
RD UP	RD DOWN	613
MDF UP	MDF DOWN	614
MDR UP	MDR DOWN	615
A LOCK L	A LOCK R	616
INNER IN	INNER OUT	635
OUTER IN	OUTER OUT	636
		637
		638
		639

		640
		641
FRONT G/N TOWER LIFT RAISE	FRONT G/N TOWER LIFT LOWER	648
FRONT G/N TOWER TILT RAISE	FRONT G/N TOWER TILT LOWER	649
FRONT G/N SUPPORT RAISE	FRONT G/N SUPPORT LOWER	650
REAR G/N TOWER LIFT RAISE	REAR G/N TOWER LIFT LOWER	651
REAR G/N TOWER TILT RAISE	REAR G/N TOWER TILT LOWER	652
REAR G/N SUPPORT RAISE	REAR G/N SUPPORT LOWER	653
APPROACH DOWN	APPROACH UP	656
		663
		664
		665
		666
		667
		668
		669
		670
		671

		672
LOAD	UNLOAD	673
SHEET OPEN	SHEET CLOSED	675
SWEEP		676
UNDER BAR UP	UNDER BAR DOWN	677
Dead man	Dead man	685
		687
		688
BIN 1 OPEN	BIN 1 CLOSE	692
BIN 2 OPEN	BIN 2 CLOSE	693
BIN 3 OPEN	BIN 3 CLOSE	694
CONV. LIFT	CONV. LOWER	695
BRAKE	OPEN GATEVALVE CLOSE	698
		709
SCOPE IN	SCOPE OUT	710
PIVOT LEFT	PIVOT RIGHT	713
SOLAR 1 UP	SOLAR 1 DOWN	714
SOLAR 2 UP	SOLAR 2 DOWN	715

Miscellaneous

 S1		 S1	729
 S2		 S2	730
 S3		 S3	731
 V1		 V1	732
 V2		 V2	733
RADIO LATCH 1		RADIO LATCH 2	742
PUSH PUSH LATCH		PUSH PUSH LATCH	743
MULTI OUT 1		MULTI OUT 2	744
SCREEN ON		SCREEN OFF	754
		LMD	755
ARCH ROTATE ₅		AUTO/MANUAL ₆	792
		POWER PACK	823
		RELEASE FRONT BRAKES	824
VAC BREAKER OPEN		VAC BREAKER CLOSE	835
DRIBBLE BAR OPEN		DRIBBLE BAR CLOSE	841
MACERATOR ON		MACERATOR OFF	842
CHANGE OVER SPREAD		CHANGE OVER FILL	843
SPREAD PLATE OPEN		SPREAD PLATE CLOSE	844

FRONT VALVE OPEN		FRONT VALVE CLOSE	848
 		RAPID	855
VAC BREAKER OPEN		VAC BREAKER CLOSE	859
CAMERA 1		CAMERA 2	865
CAMERA 3		CAMERA 4	866
ON LEFT FRONT ROLLERS		OFF LEFT FRONT ROLLERS	869
ON LEFT REAR ROLLERS		OFF LEFT REAR ROLLERS	870
ON RIGHT FRONT ROLLERS		OFF RIGHT FRONT ROLLERS	871
ON RIGHT REAR ROLLERS		OFF RIGHT REAR ROLLERS	872
VAC ON		VAC OFF	967